FRAME AND CONSOLE PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)

UNDERCOUNTER
DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1		Console (Includes Item 2)
	3375293	Black
	3375294	White
	3375295	Almond
2		Insert, Console
	3374805	Black
	3374806	White
	3374807	Almond
3	3375556	Control, Electronic
4	3376359	Fuse, Thermal
5	3374762	Switch, Display
7	304231	Screw, 8−18 x 1/2 (5)
8		Door Frame (Includes Item 26)
	3374711	Black
	3374712	White
	3374713	Almond
9	3368953	Bolt, Latch
10	3369457	Lever, Latch
	3369457	Black
	3372231	White
	3375061	Almond
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3378771	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw, 8−32 x 1/4
16	3375473	Cover Timer
17	3374501	Motor, Dual
18	3374777	Door, Sound Absorber
19		†Panel, Front
	3369516	(Almond/Black)
	3369769	(Black/White)
20		Retainer, Panel
	3374010	Black
	3374011	White
	3374012	Almond
26	3374716	Channel, Retainer (Also Order Item #20)
27	3373234	Bearing, Spring (2)

†Refer To Dishwasher Replacement Panel Parts List No. 675345.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3371480	Inner Door (Also Order Latch Door Kit 676413)
2	3376066	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
6	3369448	Draw Bar, Electronic
7	3374771	Clip, Console Door Retainer
8	3368999	Spring (Draw Bar)
9	3376404	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3369512	Wet−Agent Cap Assembly
14	3369155	Seal (Wet−Cap)
15	3369051	Screw (9)
16	3371569	Cover, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	3375130	Tub Assembly
2	3369078	Tub, Wheel Assembly (8)
3	3368933	Runner (2)
4	3376439	Leveler (2)
5	3370389	Screw, Shoulder (2)
6	302819	Wheel (2)
7	343641	Screw, 10−16 x 1/2 (4)
8	3374719	Plate, Latch
9	3374720	Screw
10	3376927	Gasket
11		Retainer, Access
	3372412	Black
	3372413	White
	3372414	Almond
		Panel
12	3369052	Deflector (2)
13	3376843	Heater
14	717273	Washer, Rubber (2)
15	3369073	Nut (2) (Heater Terminal)
16	3378779	Water Valve
17	304392	Screw, 8−18 x 1/2
18	3370783	Thermostat, Hi−Limit
20	301958	Clamp
21	3376149	Shield, Thermostat
22	3374767	Insulation, Toe & Access Panels
23	98997	Clip, Harness
25	304231	Screw, 8−18 x 1/2
26	3382404	Sound Shield
28	3374343	Spring, Door (2)
29	3369048	Housing, Float Switch
30	3369067	Switch, Float
31	3369049	Cover, Switch Housing
32	3376397	Float & Washer Assembly
33	717488	Nut
34		Toe Panel (Includes Item 22)
	3375423	Black
	9742869	White
	9742870	Almond
35		Panel, Access
	3369193	Black
	3369614	White
	3377698	Almond
36	302868	Screw, 8−18 x 1/2 (4)
37	3369414	Hose, Inlet
39	3378123	Clip, Grounding
40	9743172	Sound Shield
41	3370292	Terminal Box
42	300068	Cover Assembly, Terminal Box
43		†Access Panel
	3370868	(Black/White)
	3369527	(Almond/Black)
44	3369526	Spacer, Corrugated
45	3374728	Extension & Clip Assembly
49	3378595	Bracket, Thermostat
51	304666	Retainer, Push (2)
52	3368987	Support, Heater (3)
53	3371578	Screw, 8−32 x 1/2
54	3371579	Nut, 8−32
55	3370307	Strain Relief
56	3369138	Screw, 8−18

†Refer To Dishwasher Replacement Panel Parts List No. 675345.

PUMP AND MOTOR PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.
3	9741232	Screw, 8−18 x 5/8
4	302710	Seal, Inlet Base
5	302709	Ball, Check
6	95080	"O" Ring
7	302721	Cover, Valve
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.
9	303882	Separator Assembly (Includes Items 12, 13 & 22) See Note A.
10	3400001	Screw, 8−16 x 1−5/8 (4)
11	303510	Impeller, Wash (Includes Items 12 & 13)
12	3371152	Screw & Seal, 10−32 x 3/4
13	302711	Seal, Pump Outlet
14	3369478	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	3376752	Pump & Motor Assembly (Includes Item 16)
18	302707	Bushing, Grind
19	302718	Chopper Kit (Also Order Item 30) See Note A.
20	302705	Sleeve, Drain Impeller
21	9741321	Screw, 8−18 x 5/8
22	302704	Seal, Drain Cover
23	3378207	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	3376157	Base, Pump (Also Order Item 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.)
28	3376765	Motor (Includes Item 27) (Also Order Item 30) See Note A.
29	3369331	Screw (4)
30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
31	303918	Tool, Pump Centering
32	356138	Clamp, Hose
33	3374077	Hose, Drain
34	3371748	Cap, Drain
35	3374757	Shaft, Absorber
36	3374756	Weight, Absorber
37	3378083	Thermostat
38	3376723	Seal, O−Ring
39	3376358	Retainer, Thermostat
40	9740674	Gasket, Drain Cover

NOTE A:
Pump Centering Tool Required For Pump Re−Assembling—Order Item 31.

DISHRACK PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	303722	Clip
2	3368290	Support, Arm (Also Order Items 1 & 8)
3	3368300	Spray Arm, Upper (Also Order Items 1 & 8)
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3376961	Wheel & Transport Assembly (4)
7	3375100	Dishrack, Lower (Includes Items 4 & 6)
8	3374702	Support, Lock Spray Arm
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
12	3379489	Track
13	301077	Screw (8)
14	3369980	Housing, Adjuster (2)
15	3369981	Worm (2)
16	3369979	Plate, Mtg. (2) (Adjuster)
17		Arm Assembly (Includes Item 15)
	3369977	Right Side
	3369973	Left Side
18	3375116	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
21	3369494	Basket, Utensil
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle
25	9743472	Stop, Track (4)
26	3368629	Retainer, Flexrow
27	3375124	Flexrow

MISCELLANEOUS PARTS

For Models: DU940QWDB4, DU940QWDQ4, DU940QWDZ4
(Black) (Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

LITERATURE AND OPTIONAL PARTS

ACCESSORY PARTS

Part No.	
4317925	White
4317929	Almond
4318050	Heavy Duty

LITERATURE PARTS

Part No.	
LIT3369679	Instructions, Installation
LIT3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)
LIT3379136	Energy Guide
LIT3376819	Guide, Use & Care
LIT3379064	Tech Sheet

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

Part No.	
LIT0677967	Do−It Yourself, Manual

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

Part No.	
72017	White
72107	Almond
72032	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

Part No.	
350956	Almond
285006	Superior Black

PAINT, TOUCH−UP (1 qt.)

Part No.	
978883	Almond (Uncut)
799340	Black (Uncut)

DISHRACK REPAIR

Part No.	
675576	Vinyl Touch−Up (Blue)
675677	Tine Tip Repair Kit (Blue−− Enough For Two Complete Dishracks)
676453	Vinyl Touch−Up (White)
675679	Tine Tip Repair Kit (White−− Enough For Two Complete Dishracks)
676455	Vinyl Touch−Up (Grey)
676458	Tine Tip Repair Kit (Grey−− Enough For Two Complete Dishracks)